

Princeton Reverb Reverb Driver by Rob Robinette V1.1

B9A development board

Designed by the ValveWizard

for AX84.com

6.3V Heaters ~~Out~~

6.3V Heaters

V1B

V1A

Dry Signal Bypass

3.3M

10pF

8 Cathode 3

7 Grid 2

6 Plate 1

Grid High Pass Filter

500pF

Dry Signal In

Dry Signal Out

9 1

8 2

7 3

6 4

5 5

4 6

3 7

2 8

1 9

12AT7

Mount tube socket
on other side of board!

OUT Plate

1 2

3

Grid Leak

1M

GND

GND

Cathode

7 8

GND

250pF

2.2K

1

2

3

1

2

3

6.3v Heaters

Reverb Transformer